





Manuale di Insta	llazione, uso e manutenzione	IT
Installation, use	and maintenance manual	EN

BULLETIN MO725 ITEN\_00



# ENGLISH

**Bulletin MO725** 

**24** / 48



#### CONTENTS

1	MACHIN	E AND MANUFACTURER IDENTIFICATION	26
3			27
5	31	DEFINITION OF CLASSIFIED ZONES	27
	3.2	IGNITION HAZARDS AND PROTECTIVE MEANS IMPLEMENTED	28
	3.3	INTENDED USE	29
	3.4	HANDLING AND TRANSPORT	29
4	GENERA	L WARNINGS	30
5	<b>FIRST AI</b>	D RULES	31
6	GENERA	L SAFETY RULES	31
7	TECHNI	CAL DATA	33
8	OPERAT	ING CONDITIONS	33
	8.1	ENVIRONMENTAL CONDITIONS	33
	8.2	ELECTRICAL POWER SUPPLY	34
	8.3	ELECTRONIC ENGINE CONTROL	34
	8.4	FLUIDS PERMITTED	34
9	INSTALL	ATION	35
	9.1	POSITIONING, CONFIGURATIONS AND ACCESSORIES	35
	9.2	NOTES ON SUCTION AND DELIVERY LINES	36
10	CONNEC	CTIONS	37
	10.1	ELECTRICAL CONNECTIONS	37
	10.2	PIPING CONNECTIONS	39
11	INITIAL S	START-UP	39
12	EVERYD	AY USE	40
13	MAINTE	NANCE	41
14	NOISE L	EVEL	41
15	PROBLE	MS AND SOLUTIONS	42
16	DEMOLI	TION AND DISPOSAL	43
17	DIMENS	IONS AND EXPLODED VIEWS	44
	17.1	FEET ASSEMBLY EXPLODED VIEW (where required by model).	45



# 1 MACHINE AND MANUFACTURER IDENTIFICATION

				Suzzara (MN) Italy	ELECTRIC FUEL PUMP TYPE <b>PANTHER EX 56</b>	
	0948		EX db h	IIA T4 Gb	L.N.	
	$\cap$	UL 24 ATEX 3210 X	IECEx ULD 2	24.0012 X	Date	
	230 V 50	Hz 2.3 A	2800 rpm	Q.max 56 l/m	T <sub>a</sub> -20 °C / +50 °C	
	Insulatio	n Class F	Duty CONT	INUOUS S1	P.max 2.2 bar	
	A	WARNING: Autor	matic therma	protected motor	- not open when energized	
Examp	le of technical da	ta plate. The	values var	y depending	on the model purchased.	
AVAILA	BLE MODELS:	Panther EX 5 Panther EX 5 Panther EX 5	56 230/50 56 230/60 56 240/50			
MANUI	FACTURER:	PIUSI S.p.A. , Via Pacinotti 46029 Suzzo	16/A – z.i. I ara - (MN)	Rangavino - Italy		
THE PL	JMPS BEAR THE F	OLLOWING A	ATEX/IECE	X MARKING		
×3		Electrical ap atmosphere,	oparatus in accordo	constructed ance with Ann	and tested for use in ar ex II of Directive 2014/34/E	n explosive EU.
II	GROUP II	Equipment in other than ur criteria of the	itended for ndergroun e Directive	r use in places d sites, mines, 2014/34/EU	with presence of explosive a tunnels, etc., identified acco (ATEX).	Itmosphere, rding to the
2	CATEGORY 2	Equipment of operating policy level of protection	lesigned to irameters o ection.	o be capable established by	e of functioning in conformi y the manufacturer and ensu	ity with the uring a high
G	TYPE OF EXPLOSIVE ATMOSPHERE	Equipment ir installation ir	ntended fo n Zone 1.	r use in the p	resence of gas; Equipment	suitable for
Ex	PERMANENT PREFIX	Equipment d EN/IEC 600 with 2014/3 explosive atm	lesigned a D79 and E 54/EU), pr nospheres	nd made in a N ISO / ISO oviding a le suitable for tl	ccordance with harmonized 80079 (for presumption of vel of protection against ne installation in the declare	d standards conformity ignition in d Zone.
db	PROTECTION METHOD	Electrical ap because com	paratus no pliant with	ot able to ign hthe requirem	ite a potentially explosive on ment of IEC 60079-1 & EN 6	atmosphere 0079-1.
h	PROTECTION METHOD	Non-electrico atmosphere ISO 80079-	al apparc because c 37 and EN	itus not abl ompliant with ISO 80079-	e to ignite a potentially the requirements of ISO 8 36 & EN ISO 80079-37 (Ty	/ explosive 0079-36 & pe 'C').
IIA	GAS CLASS	Group II. Equ atmosphere IIA: a typical	ipment int other thar gas is proj	ended for use n mines susce pane.	in places with presence of exp ptible to firedamps. Group	xplosive gas Subdivision
Τ4	TEMPERA- TURE CLASS	Temperature	class T4 =	Maximum su	rface temperature 135°C.	
Gb	EQUIPMENT PROTECTION LEVEL	Level of prote normal opera in Zone 1.	ection "b" - ations and	EPL "Gb": the expected mal	e equipment is not a source of function. It is suitable for the	of ignition in installation





SEE "DECLARATION OF CONFORMITY" SHEET.

#### 3 MACHINE DESCRIPTION

PUMP

Self-priming, volumetric, rotating electric vane pump, equipped with bypass valve.

MOTOR

WARNING

Induction motor powered by alternate current, with continuous cycle, closed type, IP55 protection class according to CEI EN 60034-5, flangemounted directly to the pump body.



Motor equipped with automatic thermal overload protection. Should the protection activated, turn off the pump and wait for it to cool down.

#### 3.1 DEFINITION OF CLASSIFIED ZONES

FOREWORD



Place where an explosive atmosphere made up of a mix of air and inflammable substances in the form of gas, vapour or mist is continuously present, either for long periods or frequently.

Note: Generally speaking, said conditions, when they occur, involve the inside of tanks, pipes and containers, etc.

**ZONE1** 



Place where it is probable that an explosive atmosphere, made up of a mix of air and inflammable substances in the form of aas, vapour or mist, can occur occasionally during normal operation.

Note: Said zone can also include:

- places in the immediate vicinity of zone O;

Definition of zones as shown in directive 99/92/EC.

places in the immediate vicinity of supply openings;
 places in the immediate vicinity of filling and and emptying openings;

- places in the immediate vicinity of appliances, protection systems and fragile glass and ceramic components, or components made of other similar materials;

places in the immediate vicinity of inadequately sealed stuffing boxes, e.g. on pumps and valves with stuffing box.



Place where it is improbable that an explosive atmosphere, made up of a mix of air and inflammable substances in the form of gas, vapour or mist, can occur during normal operation, but which, if it does occur, only persists for a short time. Note: Said zone can include, among others, places surrounding the zone O or 1.



Place where an explosive atmosphere in the form of a cloud of combustible powders in the air is continuously present, either for long periods or frequently. Note: Generally speaking, said conditions, when they occur, involve the inside of tanks, pipes and containers, etc.

**ZONE 21** 



Place where it is probable that an explosive atmosphere, in the form of a cloud of combustible powders in the air, can occur occasionally during normal operation. Note: Said zone can include, for example, among others, places in the immediate

vicinity of powder loading and emptying points and places where powder layers form or which, during normal operation, could produce an explosive concentration of combustible powders mixed with the air.

Z





Place where it is improbable that an explosive atmosphere, in the form of a cloud of combustible powders in the air, occurs during normal operation but which, if it does occur, only persists for a short time.

Note: This zone can comprise, among others, places near appliances, protection systems and components containing powder, out of which the powder may leak with the formation of powder deposits (e.g., milling salt, where the powder comes out of the mills and deposits).

ZONE 1





#### 3.2 IGNITION HAZARDS AND PROTECTIVE MEANS IMPLEMENTED

Hot surfaces	The pump does not reach an external surface temperature of 135°C under any condition of use, either during normal operation or during the following foreseeable malfunctions: dry running and blocked output. A thermal sensor installed on the motor winding has been provided for this purpose, and stops the motor in the event of overheating.
Mechanically generated sparks	Moving parts do not generate sparks (bearings are self-lubricated) This instruction shows how to avoid external impact.
Electrical equipment	All electrical components are located inside the explosion-proof enclosure.
Static electricity	All materials used are in continuity or have a dimension less than 100 mm <sup>2</sup> .





#### 3.3 INTENDED USE **AUTHORIZED** PUMP FOR TRANFERRING FUEL SUITABLE FOR OPERATING IN ZONES USE CLASSIFIED"1"AND "2", ACCORDING TO DIRECTIVE 99/92/EC. THE DETERMINATION OF THE AREAS (ZONES) IS TO BE CARRIED OUT BY THE USER. FORBIDDEN Using the appliance for fluids other than those listed in paragraph "Fluids USE permitted" and for uses other than those described at the item "Authorized use" is forbidden. PLANT OPERATION RESTRICTIONS **IT IS FORBIDDEN:** 1 To use the appliance in a construction configuration other than that contemplated by the manufacturer. To use the appliance with fixed guards tampered with or removed. 2 3 To use the appliance in places where there is risk of explosion and/or fires classified in the following zones: O; 2O; 21; 22. **4** To integrate other systems and/or equipment not considered by the manufacturer in the executive project. 5 To connect the appliance up to energy sources other than those contemplated by the manufacturer. 6 To use the commercial devices for purposes other than those indicated by the manufacturer.

#### 7 To use in case of lightnings.

#### 3.4 HANDLING AND TRANSPORT

Due to the limited weight and dimensions of the pumps, special lifting equipment is not required to handle them. The pumps are carefully packed before dispatch. Check the packing when receiving the material and store in a dry place.



# 4 GENERAL WARNINGS

Important precautions	To ensure operator safety and to protect the pump from potential damage, workers must be fully acquainted with this instruction manual before performing any operation.
Symbols used in the manual	The following symbols will be used throughout the manual to highlight safety information and precautions of particular importance.
WARNING	WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
	NOTE is used for information not relating to personnel safety
Manual storage	This manual should be complete and legible throughout. It should remain available to end users and specialist installation and maintenance technicians for consultation at any time.
Reproduction rights	This manual belongs to Piusi S.p.A., which is the sole proprietor of all rights indicated by applicable laws, including, by way of example, laws on copyrights. All the rights deriving from such laws are reserved to Piusi S.p.A.: the reproduction, including partial, of this manual, its publication, change, transcription and notification to the public, distribution, marketing in any form, translation and/or processing, loan and any other activity reserved by the law to Piusi S.p.A
	THIS MANUAL IS VALID ONLY FOR AC PUMPS.
	ALWAYS USE THE RIGHT VOLTAGES TO CONNECT THE PUMPS.
	USE THE PUMP ONLY WITH FLUIDS PERMITTED. DO NOT USE WITH FLUIDS NOT PERMITTED TO AVOID DAMAGING THE PUMP. THE GUARANTEE LAPSES IN CASE OF MISUSE OF THE FLUID.
	DO NOT USE THE PUMP WITH LIQUID FOOD PRODUCTS AND/OR WATER-BASED FLUIDS.
	DO NOT OPERATE THE PUMP DRY TO AVOID DAMAGE.
	Before connection, make sure that the piping and the suction tank are free of dirt and solid residue that could damage the pump and its accessories. Never collect the fluid from the bottom of the tank since it may contain impurities.
	Keep a working fire extinguisher in the work area.
	Do not operate the unit when fatigued or under the influence of drugs or alcohol.
	Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards.
	Keep children and animals away from the work area.
	Comply with all applicable safety regulations.
	Do not use in case of lightnings.
	WHILE USING THE PUMP SWITCH OFF ALL THE ELECTRONIC DEVICES (I.E. MOBILE PHONES, BEEPERS, ETC.).

EN (Translation of the original instructions)





# 5 FIRST AID RULES

Contact with the product	For problems arising from the treated fluid in case of contact with eyes and skin or in case of inhalation or ingestion, refer to the MSDS of the fluid used.
Persons who have suffered electric shock	<ul> <li>Disconnect the power source, or use a dry insulator to protect yourself while you move the injured person away from any electrical conductor.</li> <li>Avoid touching the injured person with your bare hands until he is far away from any conductor.</li> <li>Immediately call for help from qualified and trained personnel.</li> <li>Do not operate switches with wet hands.</li> </ul>



# 6 GENERAL SAFETY RULES

USER'S RESPONSI-	IT IS ESSENTIAL TO GET TO KNOW AND UNDERSTAND THE INFORMATION CONTAINED IN THIS MANUAL.
	IT IS ESSENTIAL TO GET TO KNOW AND OBSERVE THE SAFETY SPECIFICATIONS FOR FLAMMABLE LIQUIDS.
	BEFORE USING THE PUMP IT'S IMPORTANT TO TRAIN OPERATORS, INSTALLERS AND MAINTENANCE STAFF TO LET THEM WORK IN AN AREA CLASSIFIED "1" AS MENTIONED BY DIRECTIVE 99/92/EC.
Essential protective equipment characteristics	In case of contact with the product and for good standard of behaviour, wear protective equipment which is: • suited to the operations that need to be performed; • resistant to products used To do so, please refer to the relevant technical datasheets of the fluid used.
Personal protective equipment	safety shoes.
that must be worn	protection gloves. Safety goggles.
Other devices	instructions manual.
Protective gloves	Prolonged contact with the treated product may cause skin irritation; always wear protective gloves during dispensing.
	To prevent electric shock and detonation of sparks, the entire pumping system must have proper grounding, including tank and any accessories.



	Enforce regulations for electrical installation.
WARNING	All wiring and electrical connections must be performed by authorized and suitably trained personnel.
	Never touch the electric plug or socket with wet hands.
	Do not switch the dispensing system on if the network connection cable or important parts of the apparatus are damaged, such as the inlet/outlet pipe, nozzle or safety devices. Replace the damaged pipe immediately.
IMPORTANT WARNING	The electrical connection between the plug and socket must be kept well away from water.
	The pump is equipped with current-sensing protection. If it activates turn off the pump immediately.
	The pump is equipped with protection against overheating and overload risks. Should such devices activate, the pump switches off automatically, but the master switch is not turned off. It is important to turn the pump off using its switch. The pump restarts after its normal operating conditions have been restored.
WARNING	Failure to observe the above mentioned rules can cause serious accidents.
	Should the heat sensor activate under normal use conditions, please contact the technical support.
	DO NOT OPEN THE WIRING BOX IN A CLASSIFIED AREA.
WARNING	Pay attention to hot surfaces.



#### 7 **TECHNICAL DATA**

Model	Voltage (V)	Frequency (Hz)	Max. Absorption (A)	RDM	Nominal flow rate (I/min)	Maximum pressure (bar)	By-pass pressure (bar)	Type of Service (S1-continuous; S3-periodic intermittent)
Panther EX 56 230 V/50 Hz	230	50	2.3	2800	56	1.8	2.2	S1
Panther EX 56 230 V/60 Hz	230	60	2.3	3400	56	1.8	2.2	S1
Panther EX 56 240 V/50 Hz	240	50	2.7	2800	56	1.8	2.2	S1
POWER CORD INPUT 3/4" USE	- 14 NPT CABLE	GLANE	DS WI	TH THE	APPRO	PRIATE	DEGRE	E OF

PROTECTION.

**POWER CORD** 

WARNING

IF YOU NEED TO INSTALL A THREAD ADAPTOR IN THE CABLE INPUT HOLE, IT IS NECESSARY TO MAKE SURE THAT IT FEATURES A SUITABLE PROTECTION AND THE CABLE GLAND INSTALLED MUST HAVE MINIMUM 5 FULL THREADS ENGAGED.

Minimum section recommended for cables up to 6 m: 1 mm<sup>2</sup> or **18 AWG.** Recommended sheath: HO5BN4-F T90°C, SJTW T90°C.

#### **OPERATING CONDITIONS** 8

#### 8.1 **ENVIRONMENTAL CONDITIONS**

WARNING	The temperature limits shown apply to the pump components and must be respected to avoid possible damage or malfunction.
HUMIDITY	max. 90%
TEMPERATURE	min20 °C / max +50 °C
FLUID	min4 °F / max +122 °F
TEMPERATURE	min20 °C / max +50 °C
AMBIENT	min4 °F / max +122 °F



#### 8.2 ELECTRICAL POWER SUPPLY



#### **8.3 ELECTRONIC ENGINE CONTROL**

+



The pump is equipped with a motor driving board, operated by a magnetic switch.

The table shows the technical specifications of the motor driving card and the magnetic drive.

Specification	Value
Supply	See table paragraph 7
Max. current	See table paragraph 7
Type of load	Ohmic inductive
Operating temperature	-25 °C / +65 °C (-13 °F / +149 °F)
Purpose of the control	Operational control
Control construction	Integrated control
Type of control	Туре 1
Degree of pollution	2
Impulse voltage	1500 V

WARNING

The magnetic switch does not have the function of cutting off the power.

High voltage may still be present inside the terminal block if the electrical power supply is cut only by moving the magnetic switch to the OFF position.

#### 8.4 FLUIDS PERMITTED





#### 9.1 POSITIONING, CONFIGURATIONS AND ACCESSORIES



**PANTHER EX** 

PILSI



#### 9.2 NOTES ON SUCTION AND DELIVERY LINES

#### DELIVERY

The selection of the pump model must be made taking into account the characteristics of the system. The combination of: the length of the pipe, the diameter of the pipe, the flow rate, as well as the accessories installed, could create back pressures that are greater than the maximum predicted pressure, thereby causing the pump's electronic controls to intervene and reducing the dispensed flow considerably.

In these cases, to guarantee correct operation of the pump, it is necessary to reduce the resistance of the system using pipes that are shorter or that have a greater diameter, as well as line accessories with smaller resistance (e.g. an automatic dispensing nozzle with greater flow rate capacity).

#### SUCTION

Self-priming pumps are characterized by excellent suction capacity.

During the start-up phase, when the suction pipe is empty and the pump is wet with the fluid, the electric pump unit is able to suck liquid from a maximum vertical distance of 2 m.

It is important to note that it could take up to 1 minute for the pump to prime and that the presence of an automatic dispensing nozzle on the delivery side will prevent the air trapped during the installation from being released and, therefore, the correct priming of the pump. For this reason, it is always advisable to prime the pump without an automatic delivery nozzle, verifying the proper wetting of the pump.

Always install a foot valve to prevent the suction pipe from being emptied and to keep the pump wet at all times. In this way, the pump will always start up immediately the next times it is used. When the system is in operation, the pump can operate with back pressures of up to 0.5 bars on the suction inlet; beyond this point, the pump may begin to cavitate resulting in a drop of the flow rate and an increase in the noise levels of the system.

Thus, it is important to guarantee small back pressures on the suction side, by using short pipes with diameters that are equal to or larger than those recommended, reducing bends to a minimum, and using filters with a large cross-section and foot valves with minimum possible resistance on the suction side. It is very important to keep the suction filters clean because, when they become clogged, they increase the resistance of the system.

The vertical distance between the pump and the fluid must be kept as short as possible, and not longer than max. 2 m required for priming. If the distance is greater, a foot valve must be installed to allow the suction pipes to fill up and the pipe diameter must be larger. It is however recommended that the pump is not installed if the vertical distance is greater than 3 m.

WARNING	If the suction tank is higher than the pump, an anti-siphon valve should be installed to prevent accidental diesel fuel leaks. Dimension the installation in order to control the back pressures due to water hammering.
	It is a good system practice to install vacuum and air pressure gauges right at the inlets and outlets of the pump, to allow verification that operating conditions are within specified limits. To prevent the suction pipes from being emptied when the pump stops, a foot valve should be installed.
	THE INSTALLED IS DECOMMENDED TO INSTALL A SUCTION FILTED

EN (Translation of the original instructions)



10 CC 10.1 ELI		TIONS AL CONNECTIONS
WARNING		Before any operation, ensure to be out of potentially explosive areas.
		It is the installer's responsibility to carry out the electrical connections in compliance with the relevant standards.
		Comply with the following (not exhaustive) instructions to ensure a proper electrical connection:
	- Durin lines has - Use suitable installati - Alway the powe IP55 pro	g installation and maintenance make sure that power supply to the electric s been turned off. cables with minimum sections, rated voltages and installation type that are for the characteristics indicated in paragraph "TECHNICAL DATA" and the on environment. s make sure that the cover of the terminal strip box is closed before switching on er supply, after having checked the integrity of the seal gaskets that ensure the otection grade. For those screws use a 10 Nm tightening torque.
WARNING		All motors are equipped with a grounding terminal. Make sure the entire plant is properly grounded.
		THE EXTERNAL GROUNDING CABLE MUST HAVE A MINIMUM SECTION OF 4 $\rm mm^2.$
		THE INTERNAL GROUNDING CABLE MUST HAVE A MINIMUM SECTION OF 1 $\rm mm^2.$
		MAKE SURE TO USE A CABLE GLAND, WITH SUFFICIENT PROTECTION GRADE (SEE ATEX ZONE CLASSIFICATION CH. 3.1).
WARNING		IF YOU NEED TO INSTALL A THREADED ADAPTER IN THE CABLE ENTRY HOLE, YOU MUST ENSURE THAT IT IS ATEX CERTIFIED WITH ADEQUATE PROTECTION METHOD AND THAT DURING INSTALLATION THE CABLE GLAND IS 3/4"- 14 NPT, WITH AT LEAST 5 THREADS IN THE SOCKET.
NOTE	(+)	In the event of installation in zones which are not classified, it is sufficient to observe the minimum safety standards already mentioned in this manual.
	•	<ul> <li>The owner has the responsibility to verify that all the local and national regulations have been observed.</li> <li>Ensure that the connection cable to the power supply is protected from all heat sources and sharp edges.</li> </ul>
WARNING		Failure to observe the above mentioned rules can cause serious accidents.
		Always provide a disconnect switch upstream of the electrical system.

٤x





CABLE NO.	COLOUR	SECTION	IN	OUT	CABLE GROUP
1	Green	16 AWG (1.5 mm)	÷		
2	White	16 AWG (1.5 mm)	A		Power Supply Cable
3	Black	16 AWG (1.5 mm)	В		
4	Black	18 AWG (1 mm)	MOT (L)	MOTOR	Matan Califa
5	White	18 AWG (1 mm)	MOT (N)	MOTOR	Motor Cable
6	White	18 AWG (1 mm)	Capacitor	MOTOR	Canaditan Cabla
7	Red	18 AWG (1 mm)	Capacitor	MOTOR	Capacitor Cable
8	White	14 AWG (2 mm)	D	PS (N)	hat and all Mining
9	Black	14 AWG (2 mm)	C	PS (L)	internal Wiring





#### **10.2 PIPING CONNECTIONS**





PROCEDURE	dis	pensing.		
	2 Bennoz	fore starting the pump make sure that the delivery valve is closed (dispensing zzle or line valve).		
	3 Tur	Turn the ON/OFF switch on.		
	<b>4</b> Op	Open the delivery valve, solidly grasping the pipe.		
5 While dispensing, do not inhale the pumped product.				
	6 If a ensited	any treated fluid leaks out during dispensing, take all steps necessary to sure the leaked fluid is cleaned up and safe as specified on the product hnical sheet.		
	<b>7</b> Clo	7 Close the delivery valve to stop dispensing.		
	8 Wł	nen dispensing is finished, turn off the pump.		
		The by-pass valve allows functioning with delivery closed only for short periods (max. 3 minutes). To avoid damaging the pump, after use, make sure the pump is off.		
		Should any sealants be used on the suction and delivery circuit of the pump, make sure that these products are not released inside the pump. Foreign bodies in the suction and delivery circuit of the pump could		
WARNING		The class of the screws used for the assembly of explosion-proof enclosures must be of quality higher or equal to 8.8 (ISO 898-1).		
Specific		Flameproof joints are not intended to be repaired.		
conditions		Fluid temperature range shall be from -20°C to +50°C.		

### 12 EVERYDAY USE

1 If flexible pipes are used, attach the ends of the pipings to the tanks. In the absence of an appropriate slot, solidly grasp the delivery pipe before beginning dispensing.





# 13 MAINTENANCE

Safety instructions	The pump is designed and constructed to require minimum maintenance. Before carrying out any maintenance work, disconnect the pump from any electrical and hydraulic power source. During maintenance, the use of personal protective equipment (PPE) is compulsory. In any case always bear in mind the following basic recommendations for a good functioning of the pump.	
WARNING	BEFORE ANY MAINTENANCE OPERATION, ENSURE TO BE OUT OF POTENTIALLY EXPLOSIVE AREAS.	
	FOR SAFETY REASONS IT IS FORBIDDEN TO REPAIR FLAMEPATHS. DO NOT REMOVE THE PARTS "BOTTOM PLATE" (1), "MOTOR BOX" (2), "PUMP BODY" (3) AND "TERMINAL BASE" (4).	
Authorized maintenance personnel	All maintenance must be performed by qualified personnel. Tampering can lead to performance degradation, danger to persons and/or property and may result in the warranty and ATEX CERTIFICATION being voided.	
Measures to be taken	Check that the labels and plates found on the dispensing system do not deteriorate or become detached over time.	
ONCE A WEEK	<ul> <li>Check that the pipe connections are not loose to prevent any leaks;</li> <li>Check and keep the filter installed on the suction line clean.</li> </ul>	
ONCE A MONTH	- Check the pump body and keep it clean and free of any impurities; - Check that the electrical supply cables are in good condition.	

# 14 NOISE LEVEL

Under normal operating conditions, noise emission of all models does not exceed 74 dB at a distance of 1 m from the electric pump.

R



# 15 PROBLEMS AND SOLUTIONS

For any problems contact the authorized dealer nearest to you.

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
	Lack of electric power.	Check the electrical connections and the safety systems.
THE MOTOR IS NOT TURNING	Rotor jammed.	Check for possible damage or obstruction of the rotating components.
	Motor problems.	Contact the Service Department.
THE MOTOR TURNS SLOWLY WHEN STARTING	Low voltage in the electric power line.	Bring the voltage back within the specified limits.
	Low level in the suction tank.	Refill the tank.
	Foot valve blocked.	Clean and/or replace the valve.
	Filter clogged.	Clean the filter.
	Excessive suction pressure.	Lower the pump with respect to the level of the tank or increase the cross-section of the piping.
	High loss of head in the delivery circuit (working with the by-pass open).	Use shorter piping or of greater diameter.
LOW OR NO FLOW RATE	By-pass valve blocked.	Dismantle the valve, clean and/or replace it.
	Air entering the pump or the suction piping.	Check the seals of the connections.
	Narrowing in the suction piping.	Use piping suitable for working under suction pressure.
	Low rotation speed.	Check the voltage at the pump. Adjust the voltage and/or use cables of greater cross-section.
	The suction piping is resting on the bottom of the tank.	Raise the piping.
	Cavitation occurring.	Reduce suction pressure.
INCREASED PUMP NOISE	Irregular functioning of the by-pass.	Dispense until the air is purged from the by-pass system.
	Presence of air in the fluid.	Verify the suction connections.
LEAKAGE FROM THE PUMP BODY	Seal damaged.	Check and replace the seal.
	Suction circuit blocked.	Remove the blockage from the suction circuit.
THE PUMP DOES NOT PRIME THE	Malfunction of foot valve fitted on suction circuit.	Replace foot valve.
LIQUID	The suction chambers are dry.	Add liquid from the pump delivery side.
	The pump chambers are dirty or blocked.	Remove the blockages from the suction and delivery valves.





THE HEAT SENSOR ACTIVATES UNDER NORMAL OPERATING CONDITIONS	Ambient temperature too high.	Respect the indications of the maximum ambient temperature.
THE SWITCH	Dust/dirt under the knob.	Open and clear the knob.
LEVER IS BLOCKED	Damaged spring.	Contact the Service Department.
THE SWITCH IS NOT WORKING	Magnets are damaged (corroded or broken) or missing.	Contact the Service Department.
	Electronic board is damaged.	Contact the Service Department.

# 16 DEMOLITION AND DISPOSAL

Foreword	If the system needs to be demolished, the parts which make it up must be delivered to companies that specialize in the recycling and disposal of industrial waste and, in particular:
Disposal of packing materials	The packaging consists of biodegradable cardboard, which can be delivered to companies for standard recycling of cellulose.
parts	metal collectors.
Disposal of electric and electronic components	These must be disposed of by companies that specialize in the disposal of electronic components, in accordance with the indications of directive 2012/19/EU (see text of directive below).
Information regarding the environment for	European Directive 2012/19/EU requires that all equipment marked with this symbol on the product and/or packaging not be disposed of together with non- differentiated urban waste. The symbol must indicates that this product must not be disposed of together with normal household waste. It is the responsibility of the owner to dispose of these products as well as other electric or electronic equipment by means of the specific collection structures indicated by the government or the local governing authorities. Disposing of WEEE equipment as household waste is strictly forbidden. Such waste must be disposed of separately.
clients residing within the European Union	Any hazardous substances in the electrical and electronic appliances and/or the misuse of such appliances can have potentially serious consequences for the environment and human health.
	In case of the unlawful disposal of said waste, fines will be applicable as defined by the laws in force.
Disposal of miscellaneous parts	Other components, such as pipes, rubber gaskets, plastic parts and wires, must be disposed of by companies specializing in the disposal of industrial waste.











Ä

## 17.1 FEET ASSEMBLY EXPLODED VIEW (where required by model)



# Scarica il manuale nella tua lingua! IT IT Scarica il manuale nella tua lingual EN Download the manual in your language! CS Státhnout příručku ve vašem jazyce! DA Download manualen på dit sprog! DE Laden Sie das Handbuch in Ihrer Sprache herunter! ES iDescarga el manual en tu idioma! FI Lataa käsikirja omalla kielelläsi! FR Téléchargez le manuel dans votre langue! NL Download de handleiding in uw taal! PL Pobierz instrukcje w swoim języku! TB downe ananowa servet.



- PT Baixe o manual em seu idioma! RU Загрузите руководство на вашем языке



# **BULLETIN MO725 ITEN\_00**

10.2024